

C5 RC7 SPOILER

TOOLS REQUIRED:

- 1. M6 Rivet Nut tool. A small tool to install the rivet nuts is provided but a full size tool would make the install much easier and faster.
- 2. 8mm & 5/64 Hex Key
- 3. 10mm wrench
- 4. 1/16" & 25/64" Drill bit.
- 5. Masking Tape

STEP 1

Begin with taping the top edge of the bumper to prevent any damage or scratches to the bumper. Now mock up the spoiler and center it left to right. Push it forward against the bumper and back it off approx. 1/8". Mark the 6 holes from the mounting base. Having a second person makes this much easier. NOTE: if the spoiler arrives not curved to match the bumper, simply roll/bend the center of the spoiler over your thigh a little at a time. Sometimes during shipping, the spoiler will relax and straighten out.

STEP 2

Using the smaller drill bit as a pilot, drill the marked holes followed with the larger drill bit. Take caution to not over size/drill the large hole. The rivet nuts need to have a snug fit.

STEP 3

Using the provided rivet nut tool, insert the rivet nut into the hole. With a 10mm wrench, hold the Hex Spacer and tighten the screw unit it becomes tight and the rivet nut no longer spins or is loose. Repeat for all 6 rivet nuts.

STEP 4

Mount the spoiler using the counter sunk washers and M6 screws.

STEP 5

The Lexan's screws (#6-40 x 3/8") are shipped loose to allow the spoiler to fold over the bumper. Adjust the Lexan Height if needed and tighten them down after the spoiler has been mounted.

That's it! Make sure to check all the screws after a few miles and retighten them if needed.

If you have any questions, concerns, or want to send us pictures; you can contact us at kdesignswings@gmail.com or tag us on Instagram to get featured on our feed! @K_designs_wings