

R1 SPLITTER FOR 16'-17' SILVERADO INSTALLATION

Tools needed:

1. 7/32" Hex Bit Socket
2. Drill
3. 15mm Socket/wrench
4. 10mm Socket/wrench

What's in the Box:

1. Splitter Plate
2. 6 Brackets
3. Bolts
4. Drill Bit

Steps

1. Begin by Remove the OEM plastic air dam. There are 10mm bolts all along the edge.



2. Remove the 2x 15mm bolts for the bumper bracing/strut on the body mount up front (driver and passenger side.) Install the main brackets as shown. Insure the bottom of brackets is level with bottom of bumper. Re-Use OEM Bolts.



3. Remove the bolts on the outer ends of the bumper brace/strut and install the small brackets with lower leg facing back. Re-Use OEM Bolts.



4. Remove the 2x bumper bolts in the middle and install the small brackets from above the bolt hole with lower leg facing back. Re-Use OEM Bolts.



5. Bolt the splitter plate up to the brackets using the Button Socket Screws and washers provided. Leave loose.
6. Adjust the location of the splitter by pulling it in or out to best suit your situation. Once you got it where you want it, tighten down all 8 bolts.
7. Installing the adjustable rods out front: The location for these will be up to you. You will need to use the drill bit provided to drill the holes for the rods to bolt on to. Make sure to use the washer provided on the underside of the splitter and behind the bumper so it doesn't rip through. (**NOTE**, Rods may only work if the splitter is pulled all the way out)