

R1/R2/R3 WING INSTALLATION

DISCLAIMER! Although careful thinking went into designing the wing for stability, rigidity and proper fitment, Damage may occur and we are not responsible for any damage to the vehicle, the wing or any other damage caused by it. Professional installation is highly recommended! Please read and follow the instructions below.

FOR TAILGATES WITH INTERIOR ACCESS PANELS

Tools Required:

- 3/16" Hex Socket or Allen
- Drill
- 9/32" or 5/16" Drill Bit
- Extra set of hands.

What's in the box?

- (1) R1 Wing
- (4) Stainless Steel Bolts & washers

1. Insure that the tailgate is clean from any dirt. Use water with soap to clean if necessary. Do not use other cleaning products as it may not allow the tape to stick.
2. Mask the area with tape where the mounts will land. This will protect the tailgate and allow you to clearly see where you marked the holes. Hold the wing up towards the top of the tailgate and center it from left to right and ensure the mounts are flush up against the tailgate.
3. Once you found the perfect spot, go ahead and mark the holes and drill. **Please use a pilot hole!!** Do not risk using the drill bit from the start as it may walk on you causing the holes not to line up with the spoiler.
4. Remove the tailgate's access panel from the inside.
5. Have a friend put the wing on with the screws while you reach inside and put a nut on the screw. Tighten them all up and put the access panel back on.
6. That's it! Enjoy the new wing and send us pictures at kdesignswings@gmail.com

FOR TAILGATES WITH OUT INTERIOR ACCESS PANEL

Tools Required:

- 3/16" Hex Socket or Allen
- Drill
- 25/32" Drill Bit
- Extra set of hands.

What's in the box?

- (1) R1 Wing
 - (4) Stainless Steel Bolts & washers
 - Rivet Nut & Quick Tool
7. Insure that the tailgate is clean from any dirt. Use water with soap to clean if necessary. Do not use other cleaning products as it may not allow the tape to stick.
 8. Mask the area with tape where the mounts will land. This will protect the tailgate and allow you to clearly see where you marked the holes. Hold the wing up towards the top of the tailgate and center it from left to right and ensure the mounts are flush up against the tailgate.
 9. Once you found the perfect spot, go ahead and mark the holes and drill. **Please use a pilot hole!!** Do not risk using the drill bit from the start as it may walk on you causing the holes not to line up with the spoiler.
 10. Install the rivet nut. We have a video showing how to install the rivet nut on our website under "INSTRUCTIONS".
 11. Once all rivet nuts are installed, bolt the wing on and tight it up.
 12. That's it! Enjoy the new wing and send us pictures at kdesignswings@gmail.com