

**NOTE!**

**IT IS HIGHLY RECOMMENDED TO GET THE BEZZLES PAINTED AS SOON AS POSSIBLE USING AUTOMOTIVE PAINT AND CLEAR TO PROTECT THEM.**

**Tool Required:**

- Drill
- 1/4" Drill Bit
- 3/32" Allen Key
- 5/16 Wrench

**STEP 1:**

Using the paper template provided, Hold it up to the back face of the valance and center it. Take note of where the 2 holes are facing towards the outside and the single hole is facing up and towards the middle of the truck. Mark and drill the 3 holes using a 1/4" Drill bit. Flip the template to the other side and repeat.



**STEP 2:**

Bolt up the bezel using the 3 studs & nuts from the back side. Hold on to the stud with the Allen key & tighten the nut down snugly. You can use some lock-tight if you have any in hand.

